




why! Replacing W670SZQ1 fan

Written By: Felice Suglia




Step 1 — accumulator




- Open the latch of the battery on the left side.
- Open the latch of the battery on the right side.
- Remove the battery where you simultaneously holding open the right bolt.

Step 2 — Access to major components



- Remove the Philips screwdriver to remove the two screws at the bottom of the cover.
- Lift the cover at the bottom right with the iFixit Opening Tool
- Lift the cover on the bottom left with the iFixit Opening Tool
- Finally, remove the cover so that the access to the main components is free.

Step 3 — Ventilator



- Places first the fan. Then pull out the power cable of the fan.
- Loosen the 3 fastening bolts of the fan
- Finally, remove the fan where you lift him.

Arbeite die Schritte in umgekehrter Reihenfolge ab, um dein Gerät wieder zusammenzubauen.

This document was last generated on 2017-07-03 06:11:25 AM.